

AURORA

User' Manual

AS810SD



STRIP CUT

AS810SD

User's Manual

Thank you for purchasing Strip-Cut paper shredder of the AS810SD Series. This product is ideal for home/personal and office use with its advanced function and design. We make sure that you are satisfied with its security and reliability when you deal with your documents. Please operate this machine in the right way so that prolong its using life & read this manual carefully before operating to ensure maintenance service of your paper shredder for several years.

■ Operational Instruction

1. Install the unit head on the waste bin, and connect the shredder with power source in accordance with the power specification indicated on the back of unit.
2. Please slide the switch to the "auto", the machine is at the stand-by mode. If inserting the paper in the insertion slot, the machine will start up automatically.
3. When the shredding process is over, the motor will last 2-3 seconds to clean the scrap on the blades and restore to the standby mode.
4. It is recommended not to feed over the maximized sheet each time and minimize the consecutive using time to 2 minutes to make your shredder to high efficiency.
5. If papers are being jammed in the slot or being operated continuously for a long period, then the unit will be automatically shut down because of the preset thermal protection. Please turn the power off and cool it for at least 15 minutes, then turn on the unit and it will be at standby mode again.
6. During the normal shredding process, if you would like to withdraw or pull out the half-shredder papers, please slide the switch to "rev" mode, the unit will roll the paper out immediately and return back to the standby mode.
7. When cleaning the waste bin, or not to use the machine for a long time, please set the switch to "stop" and cut off the power to ensure safety.
8. If you want to shred the credit card, please slide the switch to "auto" and insert the credit card in to the center of the paper insertion slot. You should only shred one credit card at a time. The shredder is designed for the occasional shredding of credit card.
9. This shredder features a separating slot for CD-ROM shredding. Please press the "CD destroyer/Reset" button to activate the function of shredding CD, and hold on it till the CD being shredded completely. Please shred only one CD-ROM at a time to avoid some damages for this unit.

Attention and Safety Instruction

1. Please locate the shredder at places nearby power socket for quick power disconnection in emergency.
2. Please be aware of the safety alert label on the cover of shredder. To ensure human body safety by preventing tie, jewelry or hair into the insertion slot.

3. Please don't put your hand into the insertion slot in case that contingency happened.
4. Please never place non-paper goods such as clip, plastic bag or cloth into the shredder to avoid damage and lower the shredding performance.
5. Please keep the shredder away from children and pets.
6. In order to ensure long using life and good performance of the shredder, please don't feed over the maximized capacity and run the shredder in the environment with heat or wet sources for a long time.
7. Do not renovate the internal structure of the shredder or power connection cable in any way by yourself. Do not use the shredder if the body or cable is damaged, contact with your dealer or dial the service hotline.
8. The maximized shredding capacity and continuous shredding time is changing with the different paper, different temperature & humidity.
9. The maximized shredding capacity may be reduced because of rising of motor's temperature during continuous shredding process..
10. Never use any petroleum based or flammable oils or lubricants in or around the machine as some oils can combust causing serious injury. Never spray any aerosol based products of any kind in or around shredder.

Main performance parameters.

Model : AS810SD

Shred type:	Strip cut
Cut size(mm):	6 mm
Capacity:	8 sheet (75 g/A4)
Speed:	≥3 m/min
Throat Width (mm):	230
Waste Volume (L):	12.3L
Unit Size (mm):	325x165x330
Net Weight(kg):	2.8
Main Function:	Overheat Protection/Auto Start and Stop



Important safety notes



Please read the instruction manual before using the shredder.



Do not spray or keep any aerosol products in or around shredder.



Avoid touching the document feed opening with hands.



Avoid loose clothing or jewelry touching the document feed opening.



Product is not intended for use by children. (product is not a toy).



Avoid getting hair near the document feed opening.



Do not insert foreign objects into the document feed opening.